








Examine all packaging material for small parts that may have come loose during shipment. Periodic checks are recommended to insure that all components are in proper position, tight and free from damage. Keep this assembly instruction for future reference. Adult assembly is required. Customer Service Phone Number: 502-562-0000

HARDWARE LIST

- A (6) Long Allen Bolts
- B (4) Short Head Bolts
- C (8) Large Metal Washers
- D (2) Small Metal Washers
- E (10) Spring Washers
- F (2) Wood Plugs
- G (1) Allen Wrench

PARTS LIST

- H (1) Seat Back
- J (1) Seat Base
- K (2) Arms

PART	QTY	HARDWARE
A	6	
B	4	
C	8	
D	2	
E	10	
F	2	
G	1	

STEP 1

Begin assembly by attaching both Arms (K) to Seat Back (H) using 2 Long Allen Bolts (A), 2 Spring Washers (E) and 2 Large Metal Washers (C) at the bottom. See **Figure 2**. Next, use 1 Long Allen Bolt (A), 1 Spring Washer (E) and 1 Small Metal Washer (D) at the top on the back side, per each arm. See **Figure 3**. Tighten all bolts.

STEP 2

Attach the Seat Base (J) to Seat Back (H) using 4 Short Head Bolts (B), 4 Spring Washers (E) and 4 Large Metal Washers (C) to hold in place. Tighten all bolts. See **Figure 1**. Assembly is now complete.

