

MERCANA

ART | FURNITURE | LIGHTING | DECOR



item 67683

name Connor II

wattage 3W max

socket 3X G4 LED

voltage 110 - 130v

frequency 50 - 60Hz

IMPORTANT SAFETY INSTRUCTIONS

This product has a polarized plug (one blade is wider than the other) as a feature to reduce the risk of electric shock. This plug will fit in a polarized outlet only one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Never use with an extension cord unless plug can be fully inserted. Do not attempt to defeat the safety purpose of the polarized attachment plug. Do not alter the plug.

WARNING - Deviation from the assembly instructions may result in a risk of fire or electric shock.



Different by design.

www.mercana.com

3250 189th Street
Surrey BC, Canada
V3Z 0L5

e: artinfo@mercana.com

p: 800.461.1666

f: 888.919.1666

CONSIGNES DE SÉCURITÉ IMPORTANTES

Ce produit est muni d'une fiche polarisée (une lame est plus large que l'autre). Pour des raisons de sécurité, cette fiche ne s'insère que d'une seule façon dans la prise polarisée. Si la fiche ne s'insère pas complètement dans la prise, inverser la fiche. Si vous n'arrivez toujours pas à insérer la fiche dans la prise, consultez un électricien qualifié. Ne jamais utiliser un fil de rallonge à moins que la fiche ne puisse être insérée complètement. Ne jamais tenter de déjouer le dispositif de sécurité de la fiche. Ne jamais modifier la fiche.

ATTENTION - Tout écart par rapport aux instructions d'assemblage peut entraîner un risque d'incendie ou de choc électrique.

WARNING

1. The installation work should only be performed by qualified electrician.
2. Ensure the ceiling fixture is disconnected from main power before installation.
3. Make sure the ceiling fixture is securely supported during the installation process and securely fastened to the ceiling once installation and wiring is complete.
4. Ceiling fixture is for indoor use only.

IMPORTANT

1. Wear gloves during installation to avoid scratching the lighting fixture surface
2. Do not install the ceiling fixture on a damp or damaged ceiling.
3. Ensure that the electrical supply complies with the type stated on rating label.
4. Used lighting source shall be of suitable model and wattage.
5. Avoid touching the shade and bulb when the lighting fixture is on.
6. Please turn off power and let the bulb and shade cool down before replacing the bulb and adjust the light direction.
7. Use a dry soft cloth and to clean lighting fixture.
8. If the external flexible cable or cord of lighting fixture is damaged, it shall be exclusively replaced by the manufacturer or his service agent or a similar qualified person in order to avoid a hazard.