







HOOKER[®]




— FURNITURE —

ASSEMBLY INSTRUCTION

Item#: 5751-10458-95 Writing Desk

**** Please make sure you have all parts indicated below prior to assembly.
This desk is heavy and can best be assembled with the help of two or more people.**

NO	Hardware List		Q'ty
A		35MM BOLT	8
B		LOCK WASHER	12
C		FLAT WASHER	12
D		ALLEN WRENCH	1
E		45MM BOLT	2
F		80MM BOLT	2






Diagram 3

Assembly steps:

1. Place LSF leg(H) and RSF leg (I) upside down.
2. Attach the ends of stretcher (G) to base on LSF leg(H) and RSF leg (I) by using bolts (F) (Horizontal direction),lock washers (B) and flat washers (C) ,tighten all bolts securely with allen wrench (D). (See Diagram 1).
3. Then using bolts(E)(Vertical direction),lock washers(B) and flat washers(C),tighten all bolts securely with allen wrench(D).(See Diagram 2).
4. Place desk top (J) upside down on a soft surface to prevent it from being scratched. Put whole base onto top to make sure all pre-drilled holes are in alignment, well insert bolts(A), lock washers(B) and flat washers (C), tighten bolts by turning with allen wrench (D) in clockwise direction.(See Diagram 3)
5. Turn desk upright.

Cleaning Instruction: Clean finished parts with a damp cloth using a mild dishwashing liquid and water solution. Polish the finish with soft cloth and an industry recognized furniture polish.