HOOKER®

ASSEMBLY INSTRUCTION

— F U R N I T U R E –

Item: 6150-10096-85 Desk Top 96in

6150-10084-85 Desk Top 84in

6150-10072-85 Desk Top 72in

6150-10061-85 Desk Top End Panel

Thank you for purchasing this quality product. Be sure to unpack carefully looking for small parts which may have come loose during shipment.

Read all instruction and study the drawing carefully before starting the assembly process:

HARDWARE PACK

NO	DRAWING	DESCRIPTION	SIZE	Q'TY
A	••••••	Hexagonal Bolt	Ø1/4''*2''	8pcs
В	®	Flat Washer	Ø1/4''*16*2	8pcs
С	0	Lock Washer	φ1/4''*12*3	8pcs
D	-	Screw	8#*3/4"	12pcs
Е		Allen Wrench	4mm	1pc
F		Glass support 3M	205*50*2(96in)	9pcs
G		Glass support 3M	205*50*2(84in,72in)	6pcs

