














BT-9088 PARTS

ASSEMBLY INSTRUCTION

(1)X1 	(8)X5 
(2)X1 	(9)X2 
(3)X1(L)X1(R) 	(10)X6 
(4)X1 	(11)X4 
(5)X1 	(12)X8 
(6)X1 	(13)X4 
(7)X1 	(14)X2 