
#### Item Number: A05142P3

#### WARNING (To reduce the risk of fire, electric shock, or personal injury):

- 1. We suggest installation by a **licensed electrician**.
- 2. Please read the instruction carefully and save it as you may need it at a later time.
- 3. Before you start, **NEVER** attempt any work without shutting off the electricity until the work is done.
  - » Go to the main fuse, or circuit breaker, box in your home. Place the main power switch in the "**OFF**" position.
  - » Place the wall switch in the "OFF" position.
- 4. Mounting surface should be clean, dry, flat, strong enough and 1/4" larger than the canopy on all sides. Any gaps between the mounting surface and canopy exceeding 3/16" should be corrected as required.
- 5. Make sure that the ceiling or wall can stand the weight of the lamp before installation.
- 6. Make sure the voltage you are using is 120V. The maximum wattage is LED, 15W
- 7. Keep the lamp away from acidic and alkaline substances in case of damaging the surface of the lamp.
- 8. When replacing bulbs, you should turn off or unplug the lamp and you must wait until it is cool as bulbs get hot quickly.
- 9. The safety instructions appearing in this manual are not meant to cover all possible conditions that may occur. It must be understood that common sense, caution and care must be used with any electrical products.

#### **IMAGE FOR FINISHED PRODUCT:**



# TOOLS REQUIRED (NOT INCLUDED):

Before starting assembly and installation please prepare the needed tools as below picture


				Constant
Ladder	Philips Head or Flat Blade Screwdriver	Electrical Tape	Pliers	Wire Cutter/Stripper

#### PARTS TYPE & QTY INCLUDING:

- (A) Mounting plate (1)
- (B) Green ground screw (1)
- (E) Canopy (1)
- (F) Lock nut (3)
- (G) Ball knob (2)
- (H) Cable (3)
- (I) Pipe (3)
- (J) Body (3)


# ACCESSORIES & QTY ENCLOSED:

- (C) Plastic wire connector (3)
- (D) Mounting screw (2)





#### **ASSEMBLY & INSTALLATION INSTRUCTIONS:**

- 1. Carefully remove the fixture from the carton and check that all parts and accessories are included as shown in the above illustration.
- 2 » 1) Unscrew ball knobs (G) from canopy (E).
  - 2) Gently remove mounting plate (A) out and then set them aside for later installation.



3 » Screw pipes (I) onto top of bodies (J).





# 4 » Carefully pass supply wires through mounting plate (A). Secure mounting plate (A) to the outlet box with mounting screws (D).


*NOTE: the side of mounting plate (A) marked "GND" must face out.* 

# 5. Turn off power

Before you start the installation, NEVER attempt any work without shutting off the electricity until the work is done.

- Go to the main fuse, or circuit breaker, box in your home.
   Place the main power switch in the "OFF" position.
- » Place the wall switch in the "OFF" position.
- 6 » Make wire connections

Connect wires as below wires connection shown. *PLEASE NOTE THAT GROUND WIRE IS BARE COPPER WIRE, NEVER CONNECT OTHER WIRES TO GROUND WIRES.* 




#### Connect wires according to the below chart


Connect Black or Red Supply Wire to:	Connect White Supply Wire to:		
Black	White		
*Parallel cord (round & smooth)	*Parallel cord (square & ridged)		
Clear, Brown, Gold or Black without tracer	Clear, Brown, Gold or Black with tracer		
Insulated wire(other than green) with copper conductor	Insulated wire(other than green) with silver conductor		
* Note: When parallel wires (SPT SPT II) are used. The neutral wire square shaped or ridged and the other wire will be round in shape c smooth (see illus.)	Neutral Wire		

Twist wires together with plastic wire connectors until tightly joined.
Wrap each connector with approved electrical tape.
Be sure that no wire strands are exposed and then carefully tuck all wires into the outlet box.

- 7 » 1) Raise canopy (E) to the ceiling.
  - 2) Secure canopy (E) in place by threading ball knobs (G) into canopy (E) and mounting plate (A).



- Press down and hold lock nuts (F) by hand.
- Pull or push cables (H) in and out of canopy (E) to increase or decrease the hanging height.



# **ORDERING PARTS**

Keep this sheet for future reference in case you need to order replacement parts. All parts for this fixture can be ordered from the place of purchase. Be sure to use exact wording from illustration when ordering parts.

# CLEANING

To clean, wipe the fixture with a soft cloth. Do not use abrasive materials such as scouring pads or powders, steel wool or abrasive paper.

