


VS-159



# NEED HELP?

For additional assistance or service please contact:

#### **SPEAKMAN®**



800-537-2107



customerservice@speakman.com



www.speakman.com

92-VS-159-01

# **TOOLS AND SUPPLIES**

Thread Seal 2mm Hex Key Tape Wrench (included)



Drill



1" Hole Saw



Silicone

Caulk Gun

3/8" Hex Key Wrench



#### **IMPORTANT** /





• Be sure to read instructions thoroughly before beginning installation.

### SAFETY TIPS

0

Cover your drain to prevent loss of parts. Be sure to wear eye protection while cutting pipe.


## MAINTENANCE

Your new Speakman product is designed for years of trouble-free performance. Keep it looking new by cleaning it periodically with a soft cloth. Avoid abrasive cleaners, steel wool, and harsh chemicals as these will dull the finish and void your warranty.

### WARRANTY

0


Warranty information can be found at: www.speakman.com



Apply Thread Seal Tape (not included) around Adapter Pipe threads then screw Adapter Pipe into existing Supply Pipe Coupling behind the wall. Tighten with 3/8" Hex Key (not included).

• Adapter pipe should be 7/8" to 1" from the finished wall. • Turn on water supplies and check for leaks. 1/2"-14NPT WATER INLET (NOT SUPPLIED) INSIDE THE WALL 3/8'

Slide Escutcheon over the Supply Elbow as far back as it will go.



Slide Supply Elbow over the Pipe Adapter. Center the Outlet port on the wall. Outlet port should be pointing downward when complete. Tighten Set Screws (both top and bottom) with 2mm Hex Key Wrench included.

