

CARE AND MAINTENANCE

Spot clean using a mild water-free solvent. Only a professional cleaner should undertake a complete overall cleaning.
The use of steam or water-based cleaners may cause excessive shrinking or staining.




NOTICE

- * Please make sure that you have all parts indicated before you begin assembly of this item
- * This item should be assembled on a soft surface to prevent scratching the finish during assembly
- * This item may require periodic tightening

Model# HAC4000
Product Dimensions: 74" H X 14" W X 14" D

Part List and Hardware List

PIECE	DESCRIPTION	PICTURE	QUANTITY
A	UPPER PART		1X
B	LOWER PART		1X



PREPARATION

Before beginning assembly of product, make sure all parts are present. Compare parts with package contents list and hardware contents list. If any part is missing or damaged, do not attempt to assemble the product.
Estimated Assembly Time: 3 minutes.

<p>STEP1 OPEN THE ZIPPER AND TAKE THE LOWER PART</p>	<p>STEP2 POSITIONING THE UPPER PART, POSITIONS LEARNED WITH LOWER PART</p>
<p>STEP3 TIGHTEN POSITION BY TURNING CLOCKWISE</p>	<p>STEP4 ASSEMBLY PROCESS HAS BEEN COMPLETED</p>