


## ASSEMBLY INSTRUCTION



Sunpan Item No: **107612**

Sunpan Product Name: **STATEN BENCH**

Please visit our website [www.sunpan.com](http://www.sunpan.com) for more great products.

For assembly questions please call **1-800-787-1019 (or +1-416-736-0094)** outside North America or email to [info@sunpan.com](mailto:info@sunpan.com)

### PARTS LIST

Before you begin, please layout all parts and ensure you have the correct count.

NO.	DESCRIPTION	QUANTITY	ILLUSTRATION
A	Seat	1	
B	Legs	2	
C	Stretcher	1	
D	Bolts ( Ø6*30mm)	8	
E	Lock Washers	8	
F	Washers	8	
G	Bolts ( Ø6*20mm)	4	
H	Allen Key	1	

## ASSEMBLY INSTRUCTIONS

STEP	DESCRIPTION	ILLUSTRATION
1	Attach Leg (B) to Seat (A) by using Allen Key (H) to fix Bolt (D), Lock Washer (E) & Washer (F).	
2	Attach Stretcher (C) to Leg (B) by using Allen Key (H) to fix Bolt (G).	
3	Assembly completed.	

### ASSEMBLY TIPS:

Please check parts and hardware before assembling. Follow each instruction step by step.  
 Place a protective pad or piece of cardboard on the floor while assembling your item on top of it.  
 Remove all parts from the carton and separate them into part numbers/groups as indicated on the part list.  
 Please follow instructions in the sequence as numbered to assure fast/easy assembly.

### WARNING:

Don't attempt to repair or modify parts that are broken or defective - if you find a broken part please contact us for replacement.  
 Keep all hardware parts out of the reach of children.

### FURNITURE CARE:

Following these few basic steps will help to ensure that you enjoy your furniture for a long time:  
 Do not expose your furniture to direct sunlight, dampness or any heat, like a hot cup of coffee or tea. Always use a coaster.  
 Excessive exposure to sunlight may cause fading.  
 Excessive temperature and humidity or cold may cause cracking or splitting.  
 Dust with a clean, damp, lint free cloth.  
 Use a damp cloth with water or mild detergent to clean all surfaces - do not use chemicals or paint thinner which will fade the surface.  
 Place a piece of felt or a pad under the legs of your furniture to avoid scratching the floor.