

ASSEMBLY INSTRUCTIONS

* Please keep these intructions and have the product model # and part # available when requesting a service.

MMA#811RHP - POWER RIGHT ARM	MMA#810 - MANUAL ARMLESS RECLINER
MMA#811LPH - POWER LEFT ARM	MMA#860 - ENTERTAINMENT CONSOLE
MMA#840 - ARMLESS CHAIR	MMA#850 - CORNER WEDGE
IMPORTANT NOTE Do not use a power tool to assemble this product as it could damage the thread of the hardware and affect the solidity/durability of the product.	

MADE IN VIET NAM



B x 1



MMA#811RPH - POWER RIGHT ARM

STEP 1





OFF & ON





MADE IN VIET NAM



MADE IN VIET NAM

STEP 12 3 **(4**) (5) 6 1 Slots and pins on 810, 811R, and 811L are attached to the mechanism at the bottom of the piece. To connect your sectional pieces, start with the piece on the left side when facing the sectional(#1). Hook the pins of the piece you want next to it into the slots at the bottom of item #1, continue connecting the remaining sectional pieces in order. You can configure the pieces in many ways. To disconnect, go in the reverse direction, beginning with #6. COMPLETED