




Item # : DW42RM
Assembly Instructions







*Please visit our website for the most current instructions, assembly tips, report damage, or request parts. **www.walkeredison.com***

Revised 03/2017

General Assembly Guidelines



- I. Ensure that all parts and hardware are available before beginning assembly.
- II. Follow each step carefully to ensure the proper assembly of this product.
- III. Two people are recommended for ease in the assembly of this product.
- IV. The three main types of hardware used to assemble this product are : spring washers , washers and bolts.

Hardware List


A		M6*80	Bolt	8 pcs
B		Ø1 / 4 "	Spring washer	8 pcs
C		Ø1 / 4 "	Washer	8 pcs
D		M4	Wrench	1 pc

*The hardware quantities listed above are required for proper assembly.
Some extra hardware may also have been included.*

Parts List




Step 1



Insert the legs (2) into top panel (1), use wrench (D) to secure it with bolt (A), spring washer (B) and washer (C).

Step 2



Final Assembly