Chair & Ottoman Assembly Instructions


Your chair and ottoman comes packaged in one box.

DO NOT use any sharp objects to open plastic wrapped components as damage to product or components may result.

Carefully remove all of the components from the packaging and set aside for assembly. Assemble on a soft surface to prevent scratching the finish.



Parts List		Hardware List
A 1 x Chair	■ 1 x Big Base	8 x Small Bolts M6 x 20mm
B 2 x Chair Arms	1 x Ottoman Connect Pole	① 6 x Large Bolts M8 x 55mm
© 1 x Chair Mechanism	⑥ 1 x Ottoman	10 x Flat Washers M8 x 17mm x 1mm
1 x Chair Connect Pole	1 x Small Base	4 x Lock Washers
		M 1 x Hex Key



Assembly Push the lever down to lock the seat back in place. Step 3 Pull up to unlock. Turn the knob to adjust the rocking motion. Place the lever in the unlocked position. Step 4 Loosely attach all bolts before tightening 100% Step 5

Your style may differ from images. Care for your furniture by periodically tightening all bolts using the included hex key.

One Year Warranty: The furniture is warranted against defects in workmanship and materials. Items covered would be seam slippage, frame structural integrity, fit and finish of parts. Items not covered would be product abused by the user, normal wear and tear, stains or discoloration due to use, damage in any transportation. Softening of foam is considered normal wear and tear and is not covered by warranty. Warranty is for PARTS ONLY and does not include transportation and labor costs associated with any warranty claim.

CAUTION: Tighten all components securely before use. Failure to do so may result in personal injury.

Customer Support: 866-238-0531 Mon-Fri 8:00am - 4:30pm CST customerservice@furniturequestions.com