

# ASSEMBLY AND INSTALLATION INSTRUCTIONS

CH30304 / CH30307

**WARNING:** TO AVOID RISK OF ELECTRICAL SHOCK, BE SURE TO SHUT OFF POWER WHILE INSTALLING OR SERVICING THIS FIXTURE.

NOTE: 1.Before installing, consult local electrical codes for wiring and grounding requirements.

## Installation Steps:

1. Attach the nipple-1 to the mounting strap, and secure with the washer and the hex nut.
2. Attach the mounting strap to the ceiling box by using 2 mounting screws.
3. Thread the nipple-2 into the coupling, and secure with the washer and hex nut.
4. Attach the decoration-2, decoration-1 and pipe set on to the nipple-2, and secure with the loop.
5. Choose a certain length of the chain you need, and weave the fixture wire and the grounding wire through the chain links. Spread one end of the chain link to clamp securely to the loop.
6. Secure the top loop to the nipple-1.
7. Thread the fixture wire and grounding wire through the collar, canopy, top loop, nipple-1 and mounting strap in order.
8. Clamp the other end of the chain link to the top loop.
9. Make wire connections with wire nuts:
  - Connect smooth wire (marked) from fixture to black wire from power source.
  - Connect ridged wire (unmarked) from fixture to white wire from power source.
  - Attach the grounding wire and house grounding wire to the mounting strap with the green grounding screw. Carefully tuck wires back into the ceiling box.
10. Attach the canopy to the mounting strap by inserting the top loop, and secure with the collar.
11. Attach the metal shade to the fixture by securing with the center socket ring.
12. Attach the glass shades to the fixture, and secure with the socket rings.  
Note: The glass shades should be all in horizontal line.
13. Install bulbs. (Please do not exceed the maximum capacity, which is recommended on the package.)
14. Control the lamp with the switch.

