#### FURNITURE

### Channing Desk Top and Legs

For ease of assembly two people are recommended.

Parts Included:

Table Top(A) – 1pc



Legs(B) – 2pcs



Center Stretcher (C) – 1pc



Knobs (D) – 2pcs



Hardware Included:



#### FURNITURE

Assembly Instructions:

- Remove all the components from their boxes and place them on a carpeted or scratch-free surface. Place the Leg
  (B) upright with the U-bracket on the bottom. Assemble the Center Stretcher (C) to the U-bracket of leg, secure with
  the short bolts ①, spring washers ⑤ and flat washers ⑥ using the enclosed Allen Key ③. (Step 1)
- 2. Align the other end of the stretcher with the other leg, secure with the short bolts, spring washers and flat washers as in step 1.



#### FURNITURE

3. The legs are assembled. Place the Table Top (A) upside down on a carpeted or scratch-free surface. Slightly lift the assembled legs and align the pre-drilled holes in the rails of legs with the holes in the bottom panel of Table Top. Secure them with the long bolts ②, spring washers ⑤ and flat washers ⑥ using the enclosed Allen Key ③. (Step 2). Do not over tighten bolts. Over tightening will interfere with drawer operation.



#### FURNITURE

4. Grip the table firmly at each end and turn upright. Attach the knob (D) to the drawer front, secure the screws ④, using a Phillips Head Screwdriver (not included) to turn clockwise until tight.(Step 3)



5. Assembly is complete. Due to the nature of its design the desk may have some lateral movement.

