

## CARE AND MAINTENANCE

Spot clean using a mild water-free solvent. Only a professional cleaner should undertake a complete overall cleaning.

The use of steam or water-based cleaners may cause excessive shrinking or staining.








## NOTICE

\* Please make sure that you have all parts indicated before you begin assembly of this item

\* This item should be assembled on a soft surface to prevent scratching the finish during assembly

\* This item may require periodic tightening

## Part List and Hardware List

PIECE	DESCRIPTION	PICTURE	QUANTITY
A	Seat		1X
B	Front Leg		2X
C	Back Leg		2X
HW1	Split Lock Washer(M8)		12X
HW2	Flat Washer(M8)		12X
HW3	Socket Screws 8*1.25*30MM		12X
HW4	Allen Key		1X

**The legs and hardware are located underneath the chair in the zipper compartment**

# SAFAVIEH COUTURE

SFV4700

Dimensions:32.09"WX30.31"DX31.5"H

Weight Capacity: 275 lbs



**WARNING: DO NOT STAND ON CHAIR**

**WARNING: DO NOT OVER TORQUE BOLTS/SCREWS**






## PREARATION

Before beginning assembly of product, make sure all parts are present. Compare parts with package contents list and hardware contents list.

If any part is missing or damaged, do not attempt to assemble the product.

Estimated Assembly Time: 10 minutes.

Tools Required for Assembly (included): Allen key

		
<p><b>STEP1</b> OPEN THE ZIPPER ON THE UNDERSIDE OF THE SEAT AND TAKE OUT LEGS AND HARDWARE</p>	<p><b>STEP2</b> PUT THE WASHERS ON THE SCREW IN THE ORDER SHOWN IN THE PICTURE</p>	<p><b>STEP3</b> INSERT THE LEGS AND SCREW IN THE SCREWS BUT DON'T TIGHTEN COMPLETELY. REPEAT THE SAME STEPS FOR THE OTHER THREE LEGS</p>
		
<p><b>STEP4</b> CLOSE THE ZIPPER ON THE UNDERSIDE OF THE SEAT.</p>	<p><b>STEP5</b> PUT THE CHAIR UPRIGHT AND MAKE SURE ALL LEGS ARE LEVEL, THEN FIRMLY TIGHTEN BOLTS WITH ALLEN KEY WHILE THE CHAIR IS UPRIGHT AS PICTURED ABOVE (IF THE CHAIR WOBBLING, YOU CAN EASY ADJUST LEG BOTTOM PLASTIC SCREW)</p>	
<p><b>The legs and hardware are located underneath the chair in the zipper compartment.</b></p>		