### Heart

### **Instructions**

### Fountain Installation and Care



## Parts List



#### Parts List:

A: Copper Base Pan

B: Copper Frame

C: Pump

D: Copper rock trays

E: River Rocks

# Fountain Assembly

- Remove parts from box and lay them out for ease of reference. If any parts are missing please contact customer service.
- 2. Set Base Pan down on flat level surface.



#### 3. Install pump into Copper Frame



4. Set frame in center of pan and fold down copper tabs to secure frame to pan.



5. Fill with water to ¼" below top of pan. Do not over fill.

- 6. Plug in fountain and use a wet sponge on the slate to insure water flows evenly.
- 7. Place rock trays in pan and cover with river rocks.

