


Contemporary LightingTM

PRODUCT NAME:Paddle 1-Light LED Pendant ITEM NUMBER: E24151-BK

Please consult your electrician for hanging fixture and wiring.



The fixture is designed to dim with a standard Triac forward phase dimmer. Dimming levels will vary by dimmer.

Below is a list of recommended dimmers:

Lutron DVCL-153P

Lutron SCL-153P

Leviton IPL06-10Z

Legrand DRD4

may occur.


Legrand RH703PTU

Due to inrush current wattage should not exceed 150 watts of product for a 600 watt dimmer.


WARNING: Wires need to be connected to driver found in canopy and should not be connected directly to power source or a short

Bulbs (integrated):16W LED


IMPORTANT: Turn off the power at the main fuse or circuit breaker box before starting installation




Locate all hardware & components before discarding packaging




Cleaning & Care: Clean with soft cloth and a mild detergent. Do not use abrasive cleaner.



Step 1:Remove mounting bracket from fixture and install to electrical box Mark where screws at ends of bracket meet the ceiling. Remove mounting bracket from ceiling. Drill holes using 3/16"± drill bit where marked. Install mounting bracket to outlet box and attach anchors to secure bracket at ends.



Step 2: Use push pins to adjust wires to desired mounting height. Wire fixture to wires in outlet box. See dual plastic wire instructions for more details. Install Green wire to Ground Screw.



Step 3: Install Body (B) to Mounting Bracket (A) and tighten screws on the sides of the canopy to secure