


## Parts Breakdown



**⚠ Important:** Do not plug outlet ports. Do not use diverter as shut off valve.







**⚠ Important:** Do not expose diverter valve to heat for longer than 2 minutes when sweating in copper tubing. Doing so may damage the internal components of the valve and will void the product warranty.


**Note:** Diverter valve can be installed in wall with shower valve or in an adjoining wall to shower valve.

### Replacement Parts

Item	Description	Part Number
A	Cap Assembly	RTS-DIVCAP-SRT
C	Cartridge Extender	RTS-DIVEXT-SRT
D F	Cartridge Retaining Sleeve	RTS-3DIV
B G H I	Spacer 1" Cap Extender 1" Cartridge Extender 4" Mounting Screws	RTS-DIV-1EXT

### Tools Required

Adjustable Wrench	
Drill (optional)	
Plumber Tape	
Safety Glasses	
Solder	
Torch	



**Important:** Cartridge (D) must be installed with arrow facing down.