



Item #: HT72URB
Assembly Instructions




Please visit our website for the most current instructions, assembly tips, report damage, or request parts. www.walkeredison.com

Revised 12/2017




Hardware List

Α		Ø1/4"x70mm	Bolt	2	pcs
В		Ø1/4"x35mm	Bolt	4	pcs
С		Ø1/4"x32mm	Bolt	4	pcs
D		Ø1/4"x25mm	Bolt	8	pcs
E		Ø1/4"x12mm	Bolt	8	pcs
F	{}	Ø4x12mm	Screw	4	pcs
G	D DDDDDD	Ø4x10mm	Bolt	1	рс
Н			Nut	1	рс
J	5/		Wrench	1	рс
K			L Shape Bracket	2	pcs
L		Ø6x30mm	Plug	2	pcs
М		Ø4x30mm	Screw	2	pcs
N		Ø16x6.5x1.0mm	Washer	2	pcs
0		Ø1/4x23mm	Feet	4	pcs
Р		4mm	Wrench	1	рс




Philips head screwdriver required for assembly (not included)

The hardware quantities listed above are required for proper assembly. Some extra hardware may also have been included.





Use wrench (P) to secure shelf frame (6) to side frame (2) with bolt (E) through fixed L shape bracket.


Step 2




Use wrench (P) to secure part (5) to side frame (2) with bolt (A).









bracket (K) and bolt (D) to last cross bar(3) to parts (1).






Step 9




Use wrench (J) to secure support bar (7) with bolt (G) and nut (H).



Secure support bar (7) to side frame (2) with screw (F).



Place unit in desired location and mark the wall for anchor location. Insert plug (L) into wall as per diagram.



Secure product to wall with screw (M), washer (N) through L shape bracket (K) and plug (L).

