





BT-2768L PARTS

ASSEMBLY INSTRUCTION

 ②	 (5)X1	 (2)X1
 ①	 (4)X4  (3)X4	 (1)X1