


## **GRILL CABINET**














<sup>\*</sup>Note: Do not over tighten screws




















































\*Note: Before adjusting door hinges, it is essential to ensure that grill cabinet is levelled in final resting place by adjusting leveller feet. Placing grill cabinet on an unlevelled surface without adjusting leveller feet can cause doors to become misaligned.



## Hinge Adjustment:



## \*Note: Refer to BBQ setupmanual for BBQ setup

