



Installation Guide and Users Manual



This product can expose you to chemicals including nickel, which is known to the State of California to cause cancer, and birth defects or other reproductive harm.

For more information go to www.P65Warnings.ca.gov.

Even though the materials used in all ZLINE
Kitchen and Bath products conform to all
federal government regulations and all
national product standards, California's
Prop 65 requires all businesses to provide
a "clear and reasonable warning" if one or
more listed chemicals may be present in
the product, even if that chemical is
present in trace quantities



Inspired by the clear, serene waters of the stunning Lake Tahoe, ZLINE Kitchen Faucets provide the ultimate luxury experience at the center of your home. Designed to seamlessly match every kitchen, ZLINE Faucets are offered in a wide selection of contemporary styles and designer finishes. With ergonomic control in mind, these faucets offer the perfect amount of aerated water pressure at 1.8 gal/min, allowing for an ecofriendly and efficient washing experience.

Each faucet is precision tested, as they undergo over 50,000 unit tests - a step above the industry standard of 15,000 tests. Have peace of mind knowing ZLINE Faucets are cUPC Certified, ensuring the materials used are durable and lead-free. Discover what makes Attainable Luxury® the core essence of ZLINE Kitchen with these designer kitchen faucets.

# TABLE OF CONTENTS

SAFETY INSTRUCTIONS	1
Prior to Installation	
Safety Tips	
Installation Preparation	
Care and Maintenance	
Notes	
SINGLE HANDLE/CENTERSET FAUCETS	2
Parts	
Tools	
Assembly	
DOUBLE HANDLE FAUCETS	8
Parts	
Tools	
Assembly	
TPOURIESHOOTING	12

#### SAFETY INSTRUCTIONS

#### Prior to Installation

- Make sure that the cold and hot water lines are turned off.
- Wrap all threaded connections with plumber's tape. Always wrap in a clockwise direction.
- Cover your drain to avoid losing parts.
- Do not disassemble the main faucet body, as it has been installed and commissioned correctly and precisely before delivery to the factory.
- To keep the faucet from jamming, flush the water pipe before installation.

Operating conditions: Working pressure at 0.05-1.0 MPa (including cold and hot water pressure) with applicable water temperature: 39.2°F - 194°F.

Water supply line length: 27.5"

Sprayer length: 46.5"


#### **Installation Preparation**

- 1. Shut off the water and let the water in the current faucet drain.
- 2. Assemble needed tools. The tools needed for each installation are included at the beginning of each section.
- 3. Loosen the hardware that keeps the current faucet in place. Remove faucet.


#### Care and Maintenance

To keep the product clean and shining, follow the steps below:

- 1. Rinse clean with water and dry with a soft cloth.
- 2. Do not clean with soaps, acid, polish, abrasives, or harsh cleaners.
- 3. Do not use cloth with a coarse surface.
- 4. Unscrew the aerator and clean when necessary.
- If soldering the water connections when installing the faucet, remove the O-rings, cartridges, and washers before applying any heat.
- Protect your eyes when cutting or soldering.
- Do not over tighten screws/nuts. Finger tighten, then use a wrench/Philips-head screwdriver to tighten the fixing screw/nut until snug.




- 1. Body
- 2. Washer
- 3. Washer
- 4. Nut
- 5. Pop-up
- 6. Washer
- 7. Flat washer
- 8. Nut





- 1. Body
- 2. Washer
- 3. Washer
- 4. Nut
- 5. Pop-up

#### Tools:



#### Legend:







Ø34mm (1. 34\*) Min Ø37mm (1. 46\*) Max

Loosen the fixing nut and screws for the handles and put aside.


Mount faucet to counter top.




Secure the hardware into place.




Secure the hoses to the hot (red) and cold (blue) lines appropriately.






Clear area before inserting pop-up drain stopper.

Remove the washer, flat washer, and nut from the pop-up.







Insert the pop-up from above and tighten the nut and washers below to secure to the counter top.

#### FOR MODELS WITH LIFT ROD

Set the flat rubber gasket over the drain hole in your sink, then insert the flange into the drain hole.

Insert the stopper tailpiece from above. Position the tailpiece hole to align with the hole to the side of the body.








Connect the drain lever by threading it into the hole on the side of the body. The lever must pass through the hole in the stopper tailpiece to function properly.

If not already installed, insert the faucet's lift rod into its designated hole on the back of the faucet. Attach the extension rod.


Position the drain so that the lever is facing the back of the fixture, in line with the faucet's lift rod. (See STEP 10)







Once connected, to open the drain, push down. To close the drain, pull up. Fill your sink to check for any leaks and to ensure that the drain is functioning properly.




- 1. Faucet Handle
- 2. Washer

4.

- 3. Washer
- 4. Lock Nut
- 5. Body
- 6. Washer
- 7. Washer


- 8. Nut
- 9. Adapter
- 10. Pop-up
- 11. Washer
- 12. Flat Washer
- 13. Nut

#### Tools:




#### Legend:







Loosen the fixing nut and screws for the handles and put aside.




Mount handles to the counter top.




Secure the hardware into place with the Base O-ring, nuts, and screws.




Loosen the fixing nut, washers, and adapter from the body and put aside.






Insert the body into the counter top from above and secure with nuts and washer from below.


Secure the hardware into place.



Secure the spout hose lines from the hot and cold water fixtures.





Secure the hoses to the hot (red) and cold (blue) lines appropriately.




Remove the washer flat washer and

Clear area before inserting pop-up drain stopper.







Insert the pop-up from above and tighten the nut and washers below to secure to the counter top.

Review the diagram to understand the hot, cold, and open settings.

# TROUBLESHOOTING

Problem	Possible Cause	Solution
There is leakage under the handle.	The locking nut has come loose.	Unscrew the lever on the handle by hand. Loosen set screw with a hex wrench. Remove the handle and unscrew trim cap by hand. Tighten locking nut with an
Water will not shut off completely.	Cartridge may be defective.	adjustable wrench.  Unscrew the level on the handle by hand. Loosen set screw with a hex wrench.  Remove the handle and unscrew trim cap by hand.  Unscrew the locking nut with an adjustable wrench. Remove ceramic disc cartridge. Check for cracks.
There is a leak between the spray head and the hose.	The spray head may be loose or the washer is not seated correctly in the hose connection.	Tighten the spray head by hand until snug. Make sure the washer is seated correctly.



#### Three Locations:

350 Parr Circle Reno, NV 89512

916 Delaware Avenue Marysville, OH 43040

427 Rowland Mill Road Bruceton, TN 38317

www.zlinekitchen.com

1-614-777-5004