

**COASTER**<sup>®</sup>  
FINE FURNITURE

# 700723 RIGHT MEDIA TOWER

## ASSEMBLY INSTRUCTION COASTER FINE FURNITURE



[www.coastercompany.com](http://www.coastercompany.com)

06/11/2012

# ASSEMBLY INSTRUCTIONS

## ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.














### Warning !














1. Don't attempt to repair or modify parts that are broken or defective . Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishment.

## PARTS IDENTIFICATION

Z

## HARDWARE PACKAGE


L	LEFT POST		1pc
M	RIGHT POST		1pc
N	BACK POST		1pc
O	ARC TUBE		6pcs
P	RIGHT CONNECTION TUBE		2pcs
Q	LEFT CONNECTION TUBE		2pcs
R	TOP GLASS		1pc
S	MIDDLE GLASS		1pc
T	BOTTOM GLASS		2pcs
U	CLAMP		2pcs
V	CLAMP		2pcs



NO	DESCRIPTION	FIGURE	Q`TY
1	ALLEN BOLT - LARGE		12pcs
2	ALLEN BOLT - MIDDLE		6pcs
3	ALLEN BOLT - SMALL		2pcs
4	CUP		3pcs
5	SCREW		6pcs
6	SUCTION CUP		6pcs
7	BOLT		3pcs
8	GLASS CLIP		3pcs
9	CONNECTION IRON		2pcs
10	ANCHORS		1pc
11	TIPPING RESTRAINT		1pc
12	SCREW		1pc
13	ALLEN WRENCH		1pc

STEP 1: Assemble the left connection tube to the back post.


### ASSEMBLY

Do not fully tighten all bolts until assembly is complete.  
This will help all parts to assemble properly.




2  2pcs  
13 

STEP 2: Assemble the arc tube to the front left and right post.



1  12pcs  
13 


STEP 3: Attach the right connection tube to the front frame.




Keep pier vertical and then tighten screws

STEP 4: Attach the back post to the front frame.

2		4pcs
9		1pc
13		




**STEP 5:** Insert the acetabula to the top of the post, attach the acetabula to the bolt, and then attach it to the post, and then assemble the glass clip to the post.






**STEP 6:** Carefully lift the top glass to the frame, and put the middle and bottom glass to each position.

13







STEP 7: Use the clamp to attach the TV stand and Media Tower together.

3  2pcs  
13 



STEP 8: .Drill one hole into wall with power drill, push Anchors into wall holes. Using a Phillips screwdriver, turn screw with Connection iron into Anchors.

9  2PCS  
10  1PC  
12  1PC



TO PREVENT TIP OVER PRODUCT MUST BE ATTACHED TO WALL

STEP 9: We have included one Tipping Restraint for this unit. You must connect this one to prevent accidents or injuries. When properly connected, this Tipping Restraint can provide protection against unexpected tipping of the Unit due to small tremors, bumps or climbing. We strongly recommend mounting this Tipping Restraint to a wall stud and your Unit.

