

IMPORTANT:

Turn off power at main fuse or circuit breaker box before starting assembly or relamping operation.

- 1. Carefully unpack and identify all parts before beginning assembly. Bulbs are not included.
- 2. Before proceeding with below instructions follow enclosed "Multiple Standard Fixture Installation Instructions" for electrical and fixture installation onto ceiling outlet box.
- 3. Install light bulbs (not included). See relamping label at socket area for type and maximum allowed wattage.
- 4. Lay glass plate gently at center of cover ring. Glass plate must be tucked properly at inside step of cover ring. Then, carefully holding onto cover ring push up against bottom of fixture and lock by fastening with three short machine screws.

©FEISS INDUSTRIES										
\mathbf{M}	U	\mathbf{R}	\mathbf{R}	A	Y	F	\mathbf{E}	I	S	S