



CAM LOCK SYSTEM







(2)




IMPORTANT NOTE--CAM LOCK ADJUSTMENT








If Cam Lock
is too loose,
Please adjust Metal
Dowel to turn right
as drawing.





If Cam Lock is too tight,
Please adjust Metal Dowel to turn left as drawing.












To move doors left or right, loosen screw as shown and move doors to suit. Re-tighten screw.



To move doors up or down, loosen screws as shown and move doors to suit. Re-tighten screws.

