



# 700883

**BRIDGE**

## ASSEMBLY INSTRUCTION COASTER FINE FURNITURE



[www.coastercompany.com](http://www.coastercompany.com)

## ASSEMBLY INSTRUCTION

### ASSEMBLY TIPS :


- 1.Remove hardware from box and sort by size.
- 2.Please check to see that all hardware and parts are present prior to start of assembly.
- 3.Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.









## Warning !



1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.  
2. This product is for home use only and not intended for commercial establishment.

PARTS IDENTIFICATION:






Z	HARDWARE PACKAGE						
NO	DESCRIPTION	FIGURE	Q'TY	NO	DESCRIPTION	FIGURE	Q'TY
1	GLUE 15g		1PC	4	PIPE THREAD \$ 6.2x45mm		4PCS
2	WOODEN DOWEL \$ 8x30mm		8PCS	5	BOLT \$ 4.5x20mm		4PCS
3	BOLT \$ 9.5x55mm FOR BOTTOM PANEL		12PCS	6	STICKER \$ 20mm		4PCS

STEP 1 : Insert Wooden dowel (2) into the holes on the two sides of Cross panel (B).



Apply glue on all wooden dowels to ensure integrity of the structure.



STEP 2 : Connect Cross panel (B) with Divider panel (C) by Bolt (3).  
Cover Bolts (3) with wood colored stickers (6).






**STEP 3 :** Insert Back panel (D) between Cross panel (B) along the slots.

The fasten Side panel (A) between Cross panel (B) with Bolt (3).


Cover Bolts (3) with wood colored stickers (6).

**STEP 4 :** Connect 700882 by Pipe thread (4) and Bolt (5).

Cover Pipe threads (4) and Bolts (5) with wood colored stickers (6).



STEP 5 : Install TV STAND (700881) between MEDIA TOWER (700882).



FINISH

