

MH-CH-719



ASSEMBLY INSTRUCTIONS

Do not throw away the packaging material until the assembly is complete.

To protect the product, assemble this item on a soft surface such as a cardboard or a carpet.

While assembling the product, first tighten the screws up to 50%. Once all parts are in place, only then fully tighten the screws!

CARE INSTRUCTIONS

Wipe only with a soft & dry cloth.


To protect product, avoid the use of chemicals and household cleaners.

Any liquid spilled on the product should be cleaned up immediately with a damp cloth.

PRODUCT PARTS




A
CHAIR TOP




B
CHAIR LEG

HARDWARE PROVIDED



C
BOLT
4X




D
STANDARD
WASHER
4X




E
L KEY
1X


STEP 1



Align the holes on the Chair Leg (B) with those on the Chair Top (A)



STEP 2



Once aligned, place the Bolt (C) over the standard Washer (D) and tighten using the L-Key (E)

STEP 3



Fully tighten the bolts only after all parts are in place.



Your assembly is now complete!