


CANOPY INSTALLATION INSTRUCTIONS




Attentions for lamp installation:


- 1. Please read the user manual carefully before the installation.
- 2. Please hire the professional electrician to install the lamp.
- 3. The load-bearing of the customer’ s ceiling must be over 3 times of the light weight.
- 4. The power must be cut off until the whole lamp is installed well.
- 5. To avoid getting an electric shock and cause the unnecessary hurt, please cut off the power when cleaning the lamp.

- |                            |                         |                    |
|----------------------------|-------------------------|--------------------|
| A. Existing Electrical Box | B. Crossbar             | C. Crossbar Screws |
| D. Canopy                  | E. Canopy Loop Nut lock | F. Canopy Loop     |

Light Bulb




E12




Buckle is used to connect the chain and loop or adjust the length of chain.

USER MANUAL FOR MODEL# HG8980




Light Bulb:E12      light:E12\*5  
( Rated 110-130V/60Hz, bulb 40W-60W maximum. )




**Please note: The parts in this table are completely unassembled, for illustrative purpose. In the actual product that you receive, some parts are assembled and attached together.**



Products list

NO.	Picture	Quantity
1		1 PCS
2		1 PCS
3		35 PCS

# Assembly and Installation Steps



# Product Size

