

## PARTS LIST / LISTE DES PIÈCES / LISTA DE PIEZAS

ITEM NO. /NO D'ARTICLE / ARTICULONO : P331100/111

DESCRIPTION / DESCRIPCIÓN: DRESSER / COMMODE / TOCADOR ROUND MIRROR/ MIROIR/ ESPEJO



#### WARNING

risk of furniture tipover: furniture tipover. To reduce the Children have died from


. NEVER put a TV on this product.

. NEVER open more than one or hang on drawers, doors, or shelves. . NEVER allow children to stand, climb

drawer at a time.

Place heaviest items in the







x1 Mirror Support \*x1 Supporte de miroir x1 Soporte del espejo

C

x1 Round Mirror
x1 Miroir

x1 Espejo


x1 Control para evitar vulcos


x1 Furniture Tipping Restraint \*xx1 Systeme antibasculement



((0))

x8 Flat Washer  $\phi$ 1/4"x16x2mm **\*** x8 Rondelle plate  $\phi$ 1/4"x16x2mm x8 Arandela plana \$1/4"x16x2mm





x8 Allen bolt \$\phi1/4\"x38mm ★ x8 Vis à tête creuse hexagonale \$\phi1/4\"x38mm x8 Perno Allen ø1/4"x38mm

x8 Lock washer \$\phi/4" ★
x8 Rondelle de blocage \$\phi/4"
x8 Arandela de Seguridad \$\phi/4"

\* Replaceable Part


x1 Clé hexagonale 4mm x1 Allen Key 4mm \* x1 Llave Allen 4mm



# ASSEMBLY INSTRUCTIONS / NOTICE DE MON TAGE / INSTRUCCIONES DE MONTAJE

ITEM NO. / NO D'ARTICLE / ARTICULO NO : P331100/111

DESCRIPTION / DESCRIPCIÓN : DRESSER / COMMODE / TOCADOR ROUND MIRROR/ MIROIR/ ESPEJO



\* Replaceable Part


Q



# ASSEMBLY INSTRUCTIONS / NOTICE DE MON TAGE / INSTRUCCIONES DE MONTAJE

ITEM NO. /NO D'ARTICLE/ARTICULO NO : P331100/111 DESCRIPTION /DESCRIPCIÓN : DRESSER / COMMODE / TO

DESCRIPTION / DESCRIPCIÓN : DRESSER / COMMODE / TOCADOR ROUND MIRROR/ MIROIR/ ESPEJO



\* Replaceable Part



## REPLACEABLE PART / PARTIE REMPLAÇABLE / PARTE REEMPLAZABLE

ITEM NO. /NO D'ARTICLE / ARTICULO NO : P331100/111

DESCRIPTION / DESCRIPCIÓN : DRESSER / COMMODE / TOCADOR **ROUND MIRROR/ MIROIR/ ESPEJO** 



Children have died from

risk of furniture tipover: furniture tipover. To reduce the

. **NEVER** allow children to stand, climb or hang on drawers, doors, or shelves. . **NEVER** put a TV on this product.

. NEVER open more than one drawer at a time.

Place heaviest items in the

lowest drawers. This is a permanent label.

Do not remove!



x12 RP331100-PULLL- Pull with screw Poignée + Vis Tirador + Tornillo




\*









x4 COMGLIDE-12-45-Glide 12inch 45mm \*





Deslizamiento del cajón





x4 RC-FG-WHITE-White Leveler \*

Patin réglable Nivelador



x1 RC-ANTI-TIP- Anti-tipping Restraint \*
Liste des pièces de quincaillerie antibasculement Lista del kit de materiales antivuelco







x2 RP331100-FELT -Removable Felt \* Fieltro Feutre



Q

O

Q

x1 RP331111-HWKIT-Hardware Kit 🛧 Liste des pièces de quincaillerie Lista del kit de materiales

x1 RP331111-MISU-Mirror Support \*
Supporte de miroir
Soporte del espejo



\* Replaceable Part

## **Protect Your Wood or Laminate Flooring**

\* This statement applies to any floor without carpet.

without carpet foors. The recommendation is to have felt, rubber pads or area rugs under furniture on flooring If not careful, all furniture including upholstery and case pieces can scratch, scuff and even gouge

### Moving your furniture

Pushing and dragging furniture over floor without carpet can lead to scratches and scuffs. Have someone help when moving the larger pieces of furniture by lifting, try using a dolly or moving pads.

### Felt and rubber pads

other pieces that move with use. Rubber pads will help furniture stay in place and are perfect for larger pieces, like sofas and loveseats. at local hardware stores. Felt pads slide easily across the floor, making them ideal for dining chairs and Applying furniture pads to the feet of furnitue helps cushion contact poins. Furniture pads can be found

### Area rugs and rug pads

rug pad under the area rug will provide extra cushion and added protection. Using an are rug under furniture is another way to protect your floor from scratches and scuff marks. A