# **ASSEMBLY INSTRUCTION**

# **SUNPAN**

Sunpan Product Name: IVES BED - QUEEN


Please visit our website **www.sunpan.com** for more great products

For assembly questions please call 1-800-787-1019 (or +1-416-736-0094) outside North America or email to info@sunpan.com

PARTS LIST  Before you begin, please layout all parts and ensure you have the correct count.				
PARTS	DESCRIPTION	QUANTITY	ILLUSTRATION	
А	Headboard	1		
В	Footboard	1		
С	Side Rail	2		
D	Folding Slats	1		
E	Washer (M8*20mm)	12	0	
F	Spanner (M4)	1	B	
G	Allen Key (M5)	1		

I	Inner Hexagon Screw (M8*70mm)	12	
J	Washer (M6*16mm)	4	0
K	Wing Nut(M6)	2	
L	Bolt (M6x80mm)	2	
М	Slats Middle Support Leg	2	

ASSEMBLY INSTRUCTIONS				
STEPS	DESCRIPTION	ILLUSTRATION		
1	Please connect Headboard (A) and Footboard (B) with Side Rail (C) together with Inner Hexagon Screw (I), Washer (E) and then lock well with the help of Allen Key (G).	A C G B		
2	Open the Folding Slats (D), and install the Slats Middle Support leg (M) with the Bolt (L), Washer (J) and Wing Nut (K) with the help of the Spanner (F).			



### **ASSEMBLY TIPS:**

Please check parts and hardware before assembling. Follow each instruction step by step.

Place a protective pad or piece of cardboard on the floor while assembling your item on top of it.

Remove all parts from the carton and separate them into part numbers/groups as indicated on the part list.

Please follow instructions in the sequence as numbered to assure fast/easy assembly.

# **WARNING:**

Don't attempt to repair or modify parts that are broken or defective - if you find a broken part please contact us for replacement. Keep all hardware parts out of the reach of children.

## **FURNITURE CARE:**

Following these few basic steps will help to ensure that you enjoy your furniture for a long time:

Do not expose your furniture to direct sunlight, dampness or any heat, like a hot cup of coffee or tea. Always use a coaster. Excessive exposure to sunlight may cause fading.

Excessive temperature and humidity or cold may cause cracking or splitting.

Dust with a clean, damp, lint free cloth.

Use a damp cloth with water or mild detergent to clean all surfaces - do not use chemicals or paint thinner which will fade the surface.

Place a piece of felt or a pad under the legs of your furniture to avoid scratching the floor.