


SMART TOILET INSTALLATION USER'S MANUAL



- we would like to express our most sincere thanks to you for purchasing our products!
- To avoid accidents and use this product safely, be sure to read the "Instruction Manual" carefully.
- Keep the manual in an easily accessible place and keep it in a safe place.

CONTENTS

Safety instructions	02
Safety Precautions	03
Part Name.....	05
Control Panel Features	07
Instructions for use	08
Product installation	10
Technical specifications	12

SAFETY PRECAUTIONS

★ Appearance is for reference only.

Forbid

Please note low temperature burns.

■ Even if the temperature is not high, low t emperature burns may occur if you touch the same position on the toilet seat for a long time.

■ Please pay attention to the following people. Infants, the elderly, patients, involuntary behavior Powerful, drunk, overtired.

※Seek medical attention if a low-temperature burn occurs.

Forbid

Do not step on the toilet or place heavy objects!

■ Strong impact can cause malfunctions. Do not lift or step on the body or control panel to avoid damage or personal injury.

■ Children are not easy to play with.

Must be implemented

Avoid contaminating the nozzle with excreta!

■ It can be the cause of odor or malfunction.

Must be implemented

Unplug the power plug during a lightning storm!

Must be implemented

Do not open and close the lid violently!

■ Cause failure.


Note

Do not lean on the lid and control panel!

■ It may cause failure and damage.

NOTE


1. Do not step on the body and the seat cover.
2. Do not use banana water, gasoline, medicines, cleaners or pesticides to wipe this product.
3. Sit on the smart toilet for a long time, please adjust the seat temperature to low temperature to avoid burns.The following groups of people are advised to pay attention to low temperature burns: young children, elderly, patients, unable to help themselves.People with capacity, and people taking drugs containing sleeping ingredients, drunk people,Overworked person.
4. When the product is powered on and not supplied with water, do not turn the product upside down to avoid drying the heating tube and dry burning malfunction.




(Note: The above intelligent toilet is just one of the shapes, and the actual product shall prevail.)

LIST OF MAIN MATERIALS


1.Host




2.Angle valve assembly




3.Dedicated hose




4.Sealing flange




5.user's manual



6.Remote control (with battery)



CONTROL PANEL FEATURES



1. Open key

2. Flip

3. Circle

7. Hip / Move

8. Female / Move

9. Drying

10. Flow regulation

13. Flush
4. Water temperature

5. Seat temperature

6. Wind temperature

11. Stop

12. Position adjustment

14. Nozzle

15. Power saving

16. Night Light

INSTRUCTIONS FOR USE

Note: When using for the first time, if the remote control does not respond, you need to check the code.
(When the toilet is turned off, press the side knob to the buttocks for a long time to clean, and the toilet is powered on.
Press any key on the remote control to successfully complete the code.)

Open key

This key is the key to power on. Click this button to turn on / off the power.

Circle

Press the loop button on the remote control, the cover will flip automatically.

Cover strength adjustment

In the power-on state, first press the power button on the remote control to shut down, and operate the spray lever forward and backward buttons on the remote control within 3 seconds after the cover is closed. At this time, the first operation is to light up the screen, (forward to Adjust the intensity and move backwards to decrease the intensity. There are 14 gears to adjust.) Observe the digital display on the screen to adjust. After adjusting the operation of the remote control, press and hold the power button on the remote control to start.

Hip / Move / Drying

After the human body is seated, press the "hip wash" button on the remote control or press the "hip wash" button on the remote control. The hip wash nozzle will automatically stop spraying after spraying at a fixed position for two minutes. After the stop button, the cleaning is stopped, but it is automatically switched to the warm air drying process, and the water is flushed automatically once. After the hip washing function is activated, press the hip washing button again, the nozzle will move back and forth to enhance the cleaning effect. If you press the nozzle again, it will stop the back and forth movement and stay in the working state before moving. After washing for two minutes, it will automatically enter the warm air function, or stand up to automatically stop the warm air function, or press the "dry" button on the remote control, the toilet will dry the warm air, and the warm air drying will automatically stop after 3 minutes . During the washing function, press the position adjustment "forward" or "back" button on the remote control to adjust the position of the buttocks washing nozzle forward or backward when the moving round washing function is not used. After the cleaning function is activated, press the "Stop" button or the "Stop" button on the remote control, the toilet will stop all the functions being executed.

Female / Move

After the human body is seated, the knob operates the women's flush or the "female wash" button on the remote control. The women's wash nozzle will automatically spray at a fixed position for two minutes and then automatically stop spraying. After the female washing function is activated, press the "female washing" button on the remote control or the female washing rotation of the knob again. Previous working status. During the cleaning function, press the position adjustment "forward" or "backward" button on the remote control to adjust the position of the cleaning nozzles forward or backward when the mobile shuttle cleaning function is not used. After the cleaning function is activated, press the "Stop" button on the remote control, the toilet will stop all the functions being performed.

Drying

After the human body is seated, press the host knob to stop it once or the remote control's drying button will enter the warm air to dry and flush automatically.

Flush / Stop

If this function is idle, press the "Flush" button on the remote control to activate the toilet flush function. If the AC power is off, press and hold the knob to stop the button for about 3 seconds to perform the flushing function of the toilet. At this time, the power of the backup battery is used, so this

state can only be operated when the battery is powered. The backup battery uses a 9V battery pack. The number of uses is related to the capacity of the battery used. The larger the capacity, the greater the number of times. The backup battery is only used for emergency purposes when the AC power fails. It is not recommended to use this method all the time.

Water temperature

This key is the water temperature adjustment key. Four-stage adjustment of water temperature and temperature: non-lighting is normal temperature / blue light is low temperature (about 34 ° C) / purple light is medium temperature (about 37 ° C) / red light is high temperature (about 40 ° C) four-stage cycle adjustment, Adjust it to your liking.

Seat temperature

This key is the seat temperature adjustment key. Four-stage adjustment of seat temperature and temperature: normal temperature without lights / low temperature (about 30 ° C) with blue lights / medium temperature (about 35 ° C) with purple lights and high temperature (about 40 ° C) with red lights , You can adjust it to your liking.

Position adjustment

Within 3s of shutdown, press the flip button to enter the state of adjusting the microwave distance (the range is displayed at the water temperature), the range is 1-5, the first range is the closest, and the fifth range is the furthest. The power button stops the adjustment. The detection range of the first gear is greater than 0.8 meters, the second gear is 1 meter, the third gear is 1.2 meters, the fourth gear is 1.5 meters, and the fifth gear is 1.8 meters. The third gear is the default.

Night light

When a person is not seated, the night light function key can be used to turn the lighting on or off.

Power saving

This key is a power-saving key. When the power-saving indicator is on, it enters the 8-hour power -saving mode and automatically returns to normal after 8 hours. Or in the power-saving state, the power -saving mode will be automatically released after the person is seated.

BUTTONS ON THE HOST SIDE

Press the knob once to start the drying function, and press it again to stop the current function. The water will be automatically discharged when the person leaves.



Remote control code method: Wash the hips clockwise without turning on the power. Press any button on the remote control.

User 1 / User 2 function introduction

When the human body is not seated, user 1 (seat temperature / drying / water temperature) is the highest temperature, and user 2 (seat temperature / drying / water temperature) is the lowest temperature. After the human body is seated, set the (seat temperature / drying / water temperature) temperature and press user 1 for a long time, that is, remember the current temperature settings as user 1, and add new users first (seat temperature / drying / water temperature) Press and hold User 1 after the temperature, that is, remember the current temperature as User 2.

PRODUCT INSTALLATION

Construction Points and Names of Departments

The picture is shown in Figure 1. This picture shows the main components and construction points in the construction.




figure 1

1.Preparation before installation

User-supplied tools: adjustable wrench, woodworking spirit level, Phillips screwdriver, glass glue gun, glass glue, raw material tape, tape measure, right angle ruler, electric drill, drill bit

2.Installation steps

Mark the center line of the drain on the ground, and install the water inlet angle valve at a suitable position on the wall according to the size of the toilet.

- Install the water inlet angle valve (see Figure 1)
- Construction and installation instructions (see Figure 2, Figure 3, and Figure 4)
 1. Align the wall with the centerline of the drain pipe (there are two options: 305mm and 400mm).
 2. Draw the position of the center hole (select the installation hole according to the actual needs).
 3. Gently turn the toilet sideways, and press the side of the accessory seal ring with mud to the sewage drain at the bottom of the toilet.
 4. Align the toilet drain outlet with the vertical position of the drain outlet.




figure 2





figure 3



figure 4

● Installing toilet



Tips 1:

1. The newly-renovated house is liable to damage the machine and affect human health due to residual debris such as mud and sand in the pipeline. Before installing, drain off the dirty water in the pipeline.
2. Please choose a professional installer to install this product. After installation, please carefully check whether each part is installed correctly. After 48 hours, the glass glue is completely cured before use.

Tips 2:



After connecting the water pipe to open the angle valve, if there is water flowing from the nozzle in the new product, please plug it in and it will automatically reset the nozzle and stop the water. Be sure to turn off the power and water before disassembling.

1. In the event of a power failure during the cleaning process, please do not move the spray boom. After a call, the function returns to normal after a self-test.
2. Be sure to use the special water inlet angle valve and other accessories provided by our company.

Caveat:

1. Smart toilet accessories have been debugged before leaving the factory, and unauthorized disassembly is strictly prohibited. Please use the fittings and pipes provided by our company. Old fittings and pipes cannot be reused. If you have any questions, please contact your local dealer or our after-sales service department.
2. All contents in this instruction manual are based on the latest situation of the product at the time of printing. Subject to change without notice.

CLEANING ANGLE VALVE



Turn off the angle valve switch, use a slotted screwdriver or coin tool to unscrew the back cover switch, remove the filter and clean

TECHNICAL SUPPORT

Water supply	method	Connects directly to the water pipe
	Dynamic Pressure	0.15MPa-0.75MPa(1.5kgfcm ² -7.5kgfcm ²)
Cleaning device	Hip wash water	0.5L/min-0.9L/min
	Female washing water	0.5L/min-0.9L/min
	Heating method	Instant heating
	Temperature adjustment	Normal temperature / low temperature about 34 ° C / medium temperature about 37 ° C / high temperature about 40 ° C
	Heating power	1600W
	Safety equipment	Temperature switch / Thermal fuse
Seat heating device	Temperature adjustment	Normal temperature / low temperature about 30 ° C / medium temperature about 35 ° C / high temperature about 40 ° C
Seat heating device	Heating power	50W
	Safety equipment	Recoverable / Thermal fuse / Blow fuse
Warm air drying heating device	Temperature adjustment	Normal temperature / low temperature about 45 ° C / medium temperature about 50 ° C / high temperature about 55 ° C
	Heating power	200W
	Safety equipment	Recoverable / Thermal fuse / Blow fuse
Other safety devices		Leakage protector
Power cord length		1.5m
Product Weight		40kg

SPECIFICATIONS

Smart toilet

 IPX4

Rated voltage: 110V~

Electric shock protection category I

Rated frequency: 50/60HZ

Nominal water consumption≤6.0L

Rated power: 1450W

Super high power:1650W

Implementation standards:GB4706.53-2008 JG/T 285-2010

Rated power conditions: the inlet water temperature is 15 °C, the outlet water temperature is set to the highest level and the flow rate is adjusted to the maximum

CONFIRMATION BEFORE APPLYING FOR REPAIR

Symptom	Inspection Method	Countermeasure
Does not start at all	Whether there is a power outage or the power outlet is not connected	Make sure to insert the power plug
		Please unplug and plug in again
Rinse out or get out of water	Whether water is stopped or the water supply valve is closed	Please check the water source and open the water supply valve
	Whether the water supply filter is blocked	Please clean the filter
	Whether the nozzle is clogged with scale	Please clean the nozzle with a toothbrush
Leak	Whether the water pipe connection part is tightened	Tighten the water pipe connection
Water temperature / Cool seat	Whether the water temperature and seat temperature are adjusted to normal temperature	Please readjust the temperature