



Thank you for choosing Made4home!

Our goal is to provide high quality products
with outstanding customer service-all at an affordable price.


Please let us know how we are doing!

Happy?

Please leave us a review!
You can make others happy too!



CARE INSTRUCTIONS



**PRODUCT IS INTENDED FOR INDOOR USE . THIS PRODUCT IS
CONSISTENT WITH SAFETY REQUIREMENTS**

- ☒ When in use, do not exceed the maximum load of 160 pounds

MAINTENANCE AND STORAGE:

- ☒ Acacia wood is a hard and fibrous wood.
- ☒ Avoid placing furniture in direct sunlight. Ultraviolet rays can damage wood finishes.
- ☒ Dust often using a clean, soft, dry and lint-free cloth.
- ☒ We do not recommend the use of chemical cleansers, abrasives on our product.

MADE4HOME

☒ If it is cracking and chipping occur, recommend we proceed as follows:

- Abrade the affected areas / areas in a controlled manner.
- Paint the sanded areas with a for the paint suitable use.

☒ Cushion Fabric Care:

- First step is to vacuum the fabric, removing all the dirt and dust. Then, check the care label to determine what type of cleaning agents can be used. If there is not one, spot test in a hidden area before cleaning the entire piece. Start with a gentle cleaner if possible.
- Keep upholstery from becoming flat or wrinkled by fluffing and turning detached cushions and pillows regularly.

☒ Here are four useful facts and tips to help you keep your seagrass baskets in a healthy:

- Keep it dry: it's usually better to use them indoors in a dry place. If your basket does become wet, dry them out completely – for example, by placing it under direct sunlight.
- Keep it ventilated: it's a good idea to take your basket outdoors on a dry sunny day occasionally. This will help keep your basket looking and smelling fresh.
- Don't carry heavy objects: Natural seagrass baskets look great but are not designed to carry heavy weights. One basket can carry about 2-3kgs (about 4.4lb to 6.6lb).
- Clean occasionally: Use a feather duster, a bristle paintbrush, or a similar tool to remove dirt or dust. Wipe with a damp cloth for a deeper clean. Brush or wipe in the direction of the weave to avoid pushing dust or grit under the woven materials. Let it dry fully.

DIRECTIONS FOR USE

- ☒ Install on an even floor. Do not stand/sit on the product. Do not use sharp units or pressure washer on product's surface
- ☒ Always keep the product away from heat source such as outdoor grill, flame, cigarette,...
- ☒ Active use may loosen bolts and screws to become loose. Perform a hardware check every few months or so.
- ☒ To maintain the color of the wood, you should avoid direct sunlight as far as possible.
- ☒ Please never store wooden furniture in warm, dry rooms such as Boiler rooms. This can cause hairline cracks to form favor.