


Parts Included


Wench



CSA / UL SAFETY REQUIREMENTS

CSA/UL requires that these IMPORTANT SAFETY INSTRUCTION be listed:

- ☐ Before starting installation of this fixture or removal of a previous fixture, disconnect the power by turning off the circuit breaker or by removing the fuse at the fuse box.



- ☐ Consult a qualified electrician if you have any electrical questions or need to replace the driver.

ASSEMBLY INSTRUCTIONS

LEIPZIG


429110135



Care Instructions

Arnsberg suggest using only micro fiber cleaning cloth to clean this fixture. If required, a slightly damp cleaning cloth may be used to spot clean. Do not use common household cleaners on this fixture, as the final finish may be damaged as a result. Enjoy your new Arnsberg fixture.

Mounting Instructions



ASSEMBLY INSTRUCTIONS FOR **LEIPZIG** 429110135

Assembly Instructions

1. Carefully unpack and lay out the parts as shown in the illustration.
2. Screw in the Top Tube (#4) onto Middle Tube (#3) while pulling Cord through bottom.
3. Screw the Middle Tube (#3) to the Bottom Tube (2) while pulling Cord through bottom.
4. Insert the Bottom Tube (#2) to the Base (#1), while pulling Cord through bottom.
5. Place the Lamp Plate(#7) onto the Top tube(#4) and secure it.
6. Place the Glass(#6) over the Lamp Plate(#7) ,put the screws and tighten the screws to secure the Glass(#6).