








Assembly Instructions

1600083-560


Frisly KD Shearling Fabric Bench w/ Shelf, Shearling Beige

Laying out all the parts and hardware and identifying each part as shown may help you to assemble the bench.


| PARTS | | DESC. | QTY | HARDWARE | | DESC. | QTY |
|-------|---|------------|-------|----------|---|--------------|--------|
| 1 |  | Bench top | 1 PC | A |  | Round washer | 12 PCS |
| 2 |  | Iron shelf | 2 PCS | B |  | Nut | 12 PCS |
| 3 |  | Iron leg | 2 PCS | C |  | Wrench | 1 PC |



Step 1 : Turn iron leg (3) upside down to assemble the shelf (2). Fasten the shelf with iron leg by round washer (A) and nut (B).
Note : Do not screw too tight until assemble the other side.



Step 2 : Insert the finished iron frame to the downside bench top (1). Attached them by round washer (A) and nut (B), then screw by wrench (C).



Assembly is completed. Test the stability before using.