



Design based on customers requested dimensions. Customer takes 100% responsibility for signing off and providing correct dimensions.

DESCRIPTION: SHEET: SCALE: DATE: REV: N/A 02/08/18 1/5 INSTALLATION GUIDE (REAR DUCTING BY: DE TOLERANCE: +/- 1/8" JOB: LOCATION) ... NAME SIGNATURE DATE



Design based on customers requested dimensions. Customer takes 100% responsibility for signing off and providing correct dimensions.

FINE DESIGN Johnson	0/5	INSTALLATION GUIDE (REAR DUCTING	SCALE: N/A		DATE: 02/08/18	REV: 0	
			BY: DE JOB:	•••			TOLERANCE: +/- 1/8"
NAME SIGNATURE						DATE	



## STEP 3

MEASURE AND PLACE **EXISTING DUCT SO IT** WILL COME OUT FLUSH TO THE AIR BOX BLOWER MOUNTING PLATE.

\*\*\*NOTE\*\*\* USE **DUCTING SEALANT WHEN SLEEVING DUCTING** OVER DUCTING COLLAR.

> Design based on customers requested dimensions. Customer takes 100% responsibility for signing off and providing correct dimensions.


> > REV:

SHEET: DESCRIPTION: SCALE: DATE: N/A 02/08/18 3/5 INSTALLATION GUIDE (REAR DUCTING FINE DESIGN BY: DE LOCATION) JOB: ... NAME

TOLERANCE: +/- 1/8"


SIGNATURE

DATE



Design based on customers requested dimensions. Customer takes 100% responsibility for signing off and providing correct dimensions. REV:

SHEET: DESCRIPTION: SCALE: DATE: N/A 02/08/18 4/5 INSTALLATION GUIDE (REAR DUCTING BY: DE TOLERANCE: +/- 1/8" JOB: LOCATION) ••• NAME SIGNATURE DATE



DESCRIPTION: SCALE: SHEET: DATE: REV: N/A 02/08/18 5/5 INSTALLATION GUIDE (REAR DUCTING BY: DE TOLERANCE: +/- 1/8" JOB: LOCATION) ... NAME SIGNATURE DATE