



ITEM# RV-W131-1747


IMPORTANT SAFETY INSTRUCTIONS

- To avoid injury or damage, mount only on a surface that is sturdy.
- To avoid electric shock, make sure electricity is turned off at the main circuit breaker panel. If you are replacing an existing fixture, turn off the following in order: fixture, wall switch, and main fuse or breaker box. Note: Some types of fuses must be unscrewed to shut the power off.

! For any replacement parts or installation issues, please email help@kira-home.com

*** Connect the ground wire (bare copper or green) from your fixture to the ground wire (copper or green) or ground screw in the electrical outlet box.**



Unpack the Fixture: Check the contents of the box. Box should contain all items below.



ASSEMBLY:

- 1 Secure Mounting Plate (A) to existing junction box using Mounting Screws (B) provided.

- 2 Using the wire graph below, connect the appropriate fixture wires with Wire Connectors (C) provided to the corresponding wires in the junction box.



- 3 Place Backplate (E) against wall and secure to Mounting Plate (A) using Backplate Screws (D).

- 4 Install light bulbs (not included) into Sockets (F).

- 5 Twist Glass Shades (G) over each bulb on Socket (F).
Note: Twist shades tightly to ensure they are locked into place.

Enjoy your new fixture!