


## TV Stand #J040394 Installation

Tools You Will Need: Tools You May Need







Adjustable wrench

Hexagon wrench


Philips Screwdriver


## **Before the Installation**

- 1. Do not throw away packing materials until assembly is complete for small parts may come loose inside the carton during shipment. If parts are missing, please contact us.
- 2. Assemble this item on a soft surface, such as carpet to protect the finish.
- 3. Proper assembly of this item requires 2 people.
- 4. Periodically check to ensure that all connections are tight.
- 5. It is recommended that installation of the product be done by a qualified licensed furniture assembler.

## Care and Cleaning


- 1. To protect the finish, avoid use chemicals and household cleaners.
- 2. All hot serving dishes should be placed on a pad.
- 3. Any liquid spilled onto the top should be cleaned up immediately with a damp cloth.






**Note:** Do not fully tighten all bolts until all parts are in place. Failure to follow these instructions may cause the bolt to misalign during assembly.


## **Installation Guide**






1. Match the holes of the small metal leg (E) and large metal leg (F) with holes given on the bottom of wooden shelf (B), fixing the small metal leg (E) with short screws (G). Then add the metal washers

2. Place the cabinet (C) upside down on a clean surface, then match the holes of the medium metal leg (D) with holes given on the bottom of the cabinet (C) with short screw (G).



3. Move the cabinet (C) to the wooden shelf (B).



4. Match the holes and install the wooden top
(A) to the large metal leg (F), add the metal
washers (I) and tighten long screws (H)
with Allen key (J).