

MADISONPARK® ASSEMBLY INSTRUCTIONS

Description: Annika accent chair





Important safety instructions:

- Please read carefully all instructions before assembly.
- For your safety and ease, assembly by two or more adults is recommended.
- Keep instructions for future use.


Pre-assembly:

- Do not discard any content until assembly is complete to avoid accidentally discarding small parts or hardware.
- Take out all parts and hardware from box.

Parts List

| Item | Description | | QTY |
|------|-------------|---|-----|
| P1 | Front Legs |  | 2 |
| P2 | Back Legs |  | 2 |
| P3 | Seat |  | 1 |
| P4 | Back |  | 1 |

Hardware List


| Item | Description | | QTY |
|------|----------------|---|-----|
| H1 | Plastic washer |  | 4 |

DISCLAIMER:


WHEN PROPERLY ASSEMBLED, THIS ITEM IS SAFE FOR INTENDED USE. SELLER IS NOT LIABLE FOR ANY DAMAGES RESULTING FROM ITEM BEING IMPROPERLY ASSEMBLED AFTER PURCHASE.

Assembly Procedures:


Step 1. Take out the legs from box.



Step 2. Turn the chair upside down and lay on protective carpet. Screw in the front legs (P1) and back legs (P2) using Plastic Washer (H1) for each. Screw tight to the right angle.



Step 3. Insert the back (P4) into the seat (P3) . Level the chair and place the chair upright on a level surface.



ADDITIONAL NOTE ABOUT SAFETY: BOLTS MAY LOOSEN DURING NORMAL EVERYDAY USE. THEY SHOULD BE PERIODICALLY INSPECTED AND RE-TIGHTENED TO PREVENT DAMAGE OR INJURY. ALWAYS CHECK TO ENSURE THAT ALL HARDWARE IS KEPT TIGHTENED.

Thank you for your purchase