












# BT-90275H PARTS

## ASSEMBLY INSTRUCTION

|                                                                                                        |                                                                                                   |                                                                                               |  |                                                                                                   |
|--------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------|--|---------------------------------------------------------------------------------------------------|
| <p>(1)X1</p>          | <p>(7)X1</p>     | <p>①</p>   |  | <p>②</p>       |
| <p>(2)X1</p>          | <p>(8)X5</p>     | <p>③</p>  |  | <p>④</p>      |
| <p>(3)X1(L)X1(R)</p>  | <p>(9)X4</p>     | <p>⑤</p>  |  | <p>⑥</p>     |
| <p>(4)X1</p>         | <p>(10)X8</p>    |                                                                                               |  | <p>(11)X4</p>  |
| <p>(5)X1</p>        | <p>(12)X8</p>  |                                                                                               |  | <p>(13)X1</p>  |
| <p>(6)X1</p>        |                                                                                                   |                                                                                               |  |                                                                                                   |