


Model/Le modèle: 789072


- Do not allow any sharp objects to come in contact with the cabinet, as it will scratch the surface.

- Do not put any hot appliances directly on or near the cabinet.


- Wood surfaces should only be cleaned with wood care products such as soapy water or furniture polish.




Main Body Parts/La partie principale du corps



Ceramic basin/Cuves en céramique/2



Main cabinet/Armoires principal/1



Mirror/Miroirs/2


Installation Parts/Partie d'installation




Install Screw/I'installation vis/2

- Les surfaces ne doivent être nettoyées qu'avec produits d'entretien du bois ou de l'eau savonneuse ou vernis pour meubles.


Installation/l'installation



Erecting Tool/Outils d'assemblage



Install, Remove, Adjust Of Top Fast Loading Hinge / Montage, démontage et réglage de la charnière de chargement rapide



Install/l'installation


Remove/mobiles

Adjust the height/Hauteur de réglage

adjust the lateral/Réglage latéral

Adjust the depth/Profondeur de réglage

Installation Instruction/Instructions d'installation



Install/l'installation

Remove/mobiles

Drawer Adjust/ tiroir ajuster

