
# INSTRUCTIONS FOR MODELS

VS-5000-E2 VS-5000-E175 VS-5000-E15



## **NEED HELP?**

For additional assistance or service please contact:

### **SPEAKMAN®**



800-537-2107 يُرْبَيَّا



customerservice@speakman.com



www.speakman.com

92-VS-5000-02

# **TOOLS AND SUPPLIES**

Thread Seal Tape (included)



Adjustable Wrench



# **IMPORTANT**



Be sure to read instructions thoroughly before beginning installation. Do not overtighten any connections or damage may occur. This hand shower has an optimal operating range of 20-80 psi.

## SAFETY TIPS

0

Cover your drain to prevent loss of parts.

### **MAINTENANCE**



Periodic cleaning using a mild soap and warm water will help keep your Hand Shower's appearance in its original condition.

For best results, dry immediately with a soft, clean cloth. <u>DO NOT USE</u> harsh and/or abrasive cleaners.

On CHROME PLATED HAND SHOWERS, a two (2) part white vinegar, one (1) part water solution can be used to break down excessive mineral deposits on the sprays. Let the hand shower soak in the solution for about 1/2 hour then rinse thoroughly. Brush off any remaining mineral deposits if necessary.

 $\underline{\text{DO NOT USE}}$  the vinegar/water treatment on any finish other than Chrome.


To reduce mineral build-up, turn the handle to FLOOD position to let the water drain out after every use.

### WARRANTY

Warranty information can be found at: www.speakman.com



Ensure Hose Washer is inserted inside connector to avoid leaks. Thread remaining end of Hose to base of Hand Shower. Hand tighten.



Thread Bracket onto shower arm by turning it in a clockwise direction. Tighten with adjustable wrench

