

Components List B - Back (17" High) C - Seat (15.5" Deep) LIST OF HARDWARE NO. QTY. SCREW 7*90 2 ALLEN KEY A4

PORTABLE DRILL BIT

01

STOP! PLEASE READ FIRST:

Thank you for purchasing this item from Outdoor Interiors. Please verify all the hardware and components are included as you unpack the carton. Place the items in a safe area to avoid loss and damaging contents. Use a soft area or the empty box as a barrier on hard surfaces to assemble the item. Please note that the brass tag should be at the top and back of the bench.

ASSEMBLY TIPS: Assemble furniture on its side while following pictured instructions. Never over-tighten any screws or bolts.... It's best to assemble with 2 people. Never fully tighten any bolt/screw until all are inserted on each side, then tighten. Please visit our website if you have any question www.outdoorinteriors.com Please review the "PLEASE OIL ME" card for how to care & maintain your new furniture. Thanks enjoy.

Wicker & Eucalyptus Bench #21465GR

