

CARE AND MAINTENANCE

Spot clean using a mild water-free solvent. Only a professional cleaner should undertake a complete overall cleaning.

The use of steam or water-based cleaners may cause excessive shrinking or staining.













NOTICE

* Please make sure that you have all parts indicated before you begin assembly of this item

* This item should be assembled on a soft surface to prevent scratching the finish during assembly

* This item may require periodic tightening

Part List and Hardware List

PIECE	DESCRIPTION	PICTURE	QUANTITY
1	Sofa Back		1X
2L	Sofa&Chair Side Panel 1		3X
2R	Sofa&Chair Side Panel 2		3X
3	Chair Back		2X
4	Sofa Bottom		1X
5	Chair Bottom		2X
6	Table Apron		2X
7	Table Side Panel		2X
8	Table Top		1X
A	Allen bolt(M6x35 mm)		42X
B	Flat washer		42X
C	Allen key		1X

 **SAFAVIEH**
O U T D O O R

Model# FOX6010A / FOX6010B


LAYLA OUTDOOR LIVING SET

Product Dimensions:

20.5"x26.8"x29.5" H (Chair)

42.9"x26.8"x29.5" H (Sofa)

35.4"x19.7"x12.6" H (Table)




ATTACH YOUR RECEIPT HERE


Serial Number _____

Purchase Date _____

Before beginning assembly of product, make sure all parts are present. Compare parts with package contents list and hardware contents list. If any part is missing or damaged, do not attempt to assemble the product.
Estimated Assembly Time: 60 minutes.
Tools Required for Assembly (included): Allen Key




3



(A)

x2





M6 x 35mm

(B)

x2



4 x2



(A)

x6






M6 x 35mm

(B)




x6





5 x 2




6 x2



7



(A) x12



M6 x 35mm

(B) x12

