

INSTRUCTION MANUAL

For CLYS179-1 series

 Junction Box



Bracket



Screws



Canopy



12"x2 pcs



10" x 2 pcs




6"x2 pcs



Ring

Iron cup(inside)

Iron cup(out side)



Glass Shade(1 pcs)

IMPORTANT SAFETY INSTRUCTIONS:

1. This fixture has been rated for 1 x 40 Watt, E26 standard bulb
2. Use an authorized and certified electrician for consultation and installation
3. To avoid the risk of fire, do not exceed the recommended wattage
4. Keep away from children
5. The manufacturer and distributor accepts no liability for incorrect installation.
6. For indoor use only.

Warnings:

1. Turn-off electricity supply at main circuit panel before installing. Do not connect electricity supply until your ceiling light is fully assembled and installed.
 2. All wires are connected. Do not remove the ceiling light from its packaging by pulling on the power cord, as a bad connection may result.
- Do not touch bulb when fixture is turned on or look directly at light bulb.
Keep flammable materials away from light bulb.
4. Deviation from instructions may result in a risk of fire or electric shock.

PRODUCT DESCRIPTION:

General material: Iron & Glass

Grounded / Hardwired

TO ASSEMBLE:

1. Carefully remove all parts from the box and remove all plastic covering.
 2. Turn OFF power to the junction box where the ceiling light will be installed.
 3. Loosen the screw nuts from the canopy bracket. Attach the bracket to the ceiling with screws.
 4. Attach the rods to the iron cup accordingly. Install the canopy at last.
 5. Connect the ground wire from the fixture to the ground junction box wire (Usually the green or bare wire) and wrap the connection with electrical tape.
- Connect the hot wire to the hot junction box wire (Usually black or smooth) with a plastic wire nut and wrap the connection with electrical tape.
- Connect the neutral wire to the neutral junction box wire (Usually white or ribbed) with a plastic wire nut and wrap the connection with electrical tape.
7. Move the canopy up to the ceiling, lock it with the screw nuts.
 8. Loosen the ring in the top of the iron cup, fasten the bulb.
 9. Insert the inside small iron cup into the glass shade, match the hole with the outside iron cup.
 10. Fasten the ring so as to make the outside iron cup press the glass shade..
 11. Restore power to the junction box and test ceiling light fixture

CARE INSTRUCTIONS:

1. Make sure that the power is turned off and bulb has cooled before handling.
2. Wipe clean with a dry cloth / mild soapy solution. Do not use corrosive cleaners.
3. The cable/cord of this ceiling light cannot be replaced: If the cable is damaged, do not use the light.

