

ASSEMBLY INSTRUCTIONS

Provencal Table Lamp Set of 2 (Item#: MT153-0073)

Important Safety Instructions:

- For safety purpose, this lamp is equipped with a polarized plug (one blade is wider than the other). If the plug does not fit securely into your outlet, do not force it, contact a professional electrician. Never alter the plug.
- These instructions are provided for your safety. It is very important that they are read carefully and completely before assembling fixture.
- This fixture has been rated for up to (2) 60-watt maximum TYPE A bulbs or (2) 9W LED light bulbs (Included). To avoid the risk of fire, do not exceed the recommended wattage.
- This lighting fixture is intended for indoor, residential use.

Warning:

- Wires and cables are all attached (further wiring is not needed from consumer). When unpacking product, be careful to not pull wires as it may result in a bad connection.
- To reduce the risk of fire, electrical shock or personal injury, do not turn on lighting fixture until light bulb is installed and assembly is complete.
- Always turn off the light fixture and allow it to cool before replacing the light bulb.

Care Instructions:


- Wipe with soft dry cloth only.
- Always avoid the use of harsh chemicals or abrasives as they may damage it.

Pre-assembly:

- Remove all parts and hardware from box along with any plastic protective packaging.
- · Check that all parts listed are included.
- Do not discard any contents until after assembly is complete to avoid accidentally discarding small parts or hardware.

Component List


Part	Components	Description	Qty
Code			
А		Lamp Bodies with Socket Necks and Clear Cords	2
В		9W LED bulbs (included)	2
С		Harps	2
D		Shades	2
Е		Finials	2




Assembly Instruction:

Step 1. Unpack and place all parts on a surface or floor.


Step 2. Securely attach light bulb (B) to the socket neck of lamp body (A), then insert the harp ends (C) into the saddle of the lamp body's socket neck (A).



Step 3. Place the shade (D) over the harp (C).



Step 4. Secure the shade (D) by turning the finial (E) onto the harp top (C) clockwise until tight.



Step 5. Assembly is completed.