





CARE AND MAINTENANCE

Wipe clean with a soft cloth dampened in water and a mild soapy solution Wipe dry with a clean and dry cloth.
this shoe rack requires no maintenance
however,by keeping the Product clean and storing it properly you can enjoy it year after year

NOTICE

- * Please make sure that you have all parts indicated before you begin assembly of this item
- * This item Should be assembled on a soft surface to prevent scratching the finish during assembly
- * This item may require periodic tightening

Part List and Hardware List

PIECE	DESCRIPTION	PICTURE	QUANTITY
A	Stand		X2
B	Plate		X2
C	Cross Screw		X9
D	L key		X1

happimess

SRK1000A
PRODUCT DIMENSIONS : 38"W x12"D 10.75"H



Weight Capacity : 50 Lbs
Warning : Do not stand on Shoe Rack
Warning : Do not sit on Shoe Rack



PREPARATION

Before beginning assembly of product, make sure all parts are present. Compare parts with package contents list and hardware content list.
If any parts is missing or damaged, do not attempt to assemble the product
Estimated Assembly Time 20 minutes

