





# ASSEMBLY INSTRUCTION

Item#:3002-80116 Round Lamp Table—Beach & Dune

\*\* Please make sure you have all parts indicated below prior to assembly.



NO	HARDWARE LIST		Q'TY
A		FLAT WASHER	12
B		LOCK WASHER	12
C		BOLT	12
D		ALLEN WRENCH	1
E		PLUG	4




Diagram 1

Diagram 2

## Assembly Steps:

1. Place table top upside down on a soft surface to prevent from scratching top.
2. Attach two legs (G) to top(F) using 2 bolts (C), 2 lock washers (B), 2 flat washers (A) for each, secure by turning with Allen wrench (D) in a clockwise direction. (See diagram 1).
3. Attach two ends of stretchers(H) to legs using 2 bolts (C), 2 lock washers (B), 2 flat washers (A),secure by turning with Allen wrench (D) in a clockwise direction. (See diagram 2).
4. Attach the other two legs to top as the same way on step 2.
5. Attach the other two ends of the stretchers to legs as the same way on step 3.
6. Cover bolt hole on the stretcher by plug (E). And turn table upright.

**Caution: Do not over tighten.**

*Cleaning Instruction: Clean finished parts with a damp cloth using a mild dishwashing liquid and water solution. Polish the finish with soft cloth and an industry recognized furniture polish.*