


ASSEMBLY INSTRUCTION

SUNPAN



Sunpan Product Name: **PALOMA DINING TABLE - ROUND**

Please visit our website www.sunpan.com for more great products

For assembly questions please call **1-800-787-1019 (or +1-416-736-0094)** outside North America or email to info@sunpan.com

PARTS LIST			
Before you begin, please layout all parts and ensure you have the correct count.			
PARTS	DESCRIPTION	QUANTITY	ILLUSTRATION
A	Top	1	
B	Connecting Plate	1	
C	Base	1	
D	Bolt (Ø8*30mm)	12	
E	Washer(Ø10*1.5mm)	12	
F	Allen Key	1	

ASSEMBLY INSTRUCTIONS		
STEPS	DESCRIPTION	ILLUSTRATION
1	a: Use allen key(F) to fasten metal leg (E) by using bolt(D)	
2	B: Use allen key(F) to fasten metal leg (E) by using bolt(D)	
3	It's ready to use after screwing tightly	

ASSEMBLY TIPS:

Please check parts and hardware before assembling. Follow each instruction step by step.

Place a protective pad or piece of cardboard on the floor while assembling your item on top of it.

Remove all parts from the carton and separate them into part numbers/groups as indicated on the part list.

Please follow instructions in the sequence as numbered to assure fast/easy assembly.

WARNING:

Don't attempt to repair or modify parts that are broken or defective - if you find a broken part please contact us for replacement.

Keep all hardware parts out of the reach of children.

FURNITURE CARE:

Following these few basic steps will help to ensure that you enjoy your furniture for a long time:

Do not expose your furniture to direct sunlight, dampness or any heat, like a hot cup of coffee or tea. Always use a coaster.

Excessive exposure to sunlight may cause fading.

Excessive temperature and humidity or cold may cause cracking or splitting.

Dust with a clean, damp, lint free cloth.

Use a damp cloth with water or mild detergent to clean all surfaces - do not use chemicals or paint thinner which will fade the surface.

Place a piece of felt or a pad under the legs of your furniture to avoid scratching the floor.