








## ASSEMBLY INSTRUCTION





Sunpan Product Name : REBEL DESK

Please visit our website [www.sunpan.com](http://www.sunpan.com) for more great products.



For assembly questions please call 1-800-787-1019 (or +1-416-736-0094) outside North America or email to [info@sunpan.com](mailto:info@sunpan.com)

<b>PARTS LIST</b> <b>Before you begin, please layout all parts and ensure you have the correct count</b>			
NO.	DESCRIPTION	QUANTITY	ILLUSTRATION
A	Desk Cabinet	1	
B	Legs	2	
C	Screw $\varnothing 8 \times \frac{5}{8}$ "	16	
D	Ring 6 - 13mm	16	
E	Anti Tipping Kit	1 set	

# ASSEMBLY INSTRUCTIONS

STEP	DESCRIPTION	ILLUSTRATION
1	Remove packing protection and unpacking legs.	
2	Attach leg (B) to desk cabinet (A). Use screw $\text{Ø}8 \times \frac{5}{8}$ (C) with ring 6-13mm (D) to assemble by following the screw holes on bottom of cabinet, and tighten with screw driver.	

## ASSEMBLY INSTRUCTIONS

STEP	DESCRIPTION	ILLUSTRATION
3.	Move the table out from the box, and turn around to the right position.	
4	Assembly completed	

### ASSEMBLY TIPS :

Please check parts and hardware before assembling. Follow each instruction step by step.

Place a protective pad or piece of cardboard on the floor while assembling your item on top of it.

Remove all parts from the carton and separate them into part numbers / groups as indicated on the part list.

Please follow instructions in the sequence as numbered to assure fast / easy assembly.

### WARNING :

Don't attempt to repair or modify parts that are broken or defective - if you find a broken part please contact us for replacement.

Keep all hardware parts out of the reach of children.

### FURNITURE CARE :

Following these few basis step will help to ensure that you enjoy your furniture for a long time.

Do not expose your furniture to direct sunlight, dampness or any heat, like a hot cup of coffee or tea. Always use a coaster.

Excessive exposure to sunlight may cause fading.

Excessive temperature and humidity or cold may cause cracking or splitting.

Dust with a clean, damp, lint free cloth.

Use a damp cloth with water or mild detergent to clean all surfaces - do not use chemicals or paint thinner which will fade the surface.


Place a piece of felt or a pad under the legs of your furniture to avoid scratching the floor.

## ANTI TIPPING - KIT INSTALLATION INSTRUCTIONS


### READ INSTRUCTION BEFORE INSTALLING

**Caution :** This product is not a substitute for parental supervision.  
Manufacturer assumes no responsibility or liability for improper installation  
or excessive loads placed on any of the supplied components.

### EXAMPLES FOR SECURING



Attach to top back frame of cabinet  
Ideal installation for Dressers & Chests



Attach to top of tall furniture  
like curios

### NOTES :

Always mount to solid wood. Do not attach to plywood back panels.  
Always locate and attach to stud, do not depend on wall anchors.