INSTRUCTION MANUAL



A Perfect Match !





Fat

UPC#: 704129159693

UPC#: 792057864628

10 Ft. Cantilever Hanging Patio Umbrella SKU: 980-10 ft.

! CARE & MAINTENANCE

- riangle Clean with lukewarm water, mild detergent & Sponge.
- riangle Wipe down the pole with damp cloth.
- \bigtriangleup Store in a location when not in use.

() SAFETY PRECAUTIONS

- \bigtriangleup Store the umbrella in windy or stormy weather.
- riangle Do not use or store this item in the proximity of open flame or flammable/combustible chemicals.
- riangle Do not allow umbrella to flap in the wind as it may cause damage.
- riangle When adjusting umbrella, make sure no person or item is close to avoid injury or damage.







1

Place part C and D Cross Base as below and attach part B Extend Pole to part D Cross Base with 2 PCS of part 3 bolt and part 4 washer.

Then attach part B Extend Pole to part C Cross Base with 2 PCS of part 3 bolt and part 4 washer.



Turn the crank at the end of supporting pole crockwise to pull the umbrella up to the top socket.

Now you can pull up the umbrella body upward.



3

Attach part A Umbrella Body to part B Extend Pole as below.



Unlock the adjusting handle as below and adjust the supporting pole up and down to a suitable position by pushing the handle upwards or downwards.

riangle Hold the umbrella supporting pole when adjusting to avoid any injury or damage.





Lock down the adjusting handle when the umbrella supporting pole is in a suitable position.





Turn the crank at the end of supporting pole clockwise to open the umbrella while turn anti-clockwise to close the umbrella.





Push the supporting pole upward to make the connecting pole straight and the lock fixed with the connector as figure AA below.

Pull the lock downward to fix the connecting pole firmly.



